




Installation Manual for Rotatable Bracket & Microwave Sensor with Metal Balancer




Ring




Rotatable bracket



sensor bracket





Metal balancer



Microwave sensor

Rotatable bracket



Rotatable bracket



M8*20MM





M4*20MM



Gasket

Microwave sensor/Metal balancer


Install the Metal Balancer to the opposite side of the Microwave Sensor. To enhance the balance after the Microwave Sensor is being installed.




sensor bracket



M4*20MM




Metal balancer



Microwave sensor

Wiring diagram



SENSOR